


Reflected Normal Shocks

- What happens when moving shock **runs into a boundary**, e.g.,


- closed wall
- open end of a pipe



- Change in boundary conditions must be transmitted back to flow


⇒ **reflected waves**

- compressions or expansions




Closed Tube

- While (incident) shock is heading towards wall, there is flow behind it
 - but closed boundary, so no flow can go through wall




- Must generate reflected wave that stops oncoming flow
 - flow is slowed down; p, ρ increase
 - ⇒ compression ⇒ **reflected shock**



- *In lab reference frame*, $v=0$ behind reflected wave

– *shock ref. frame* ⇒ $v_{rs} = v_2$

(use this + known v_g and shock relations to find v_{rs})



Open Tube

- Now boundary condition is constant pressure at open end
 - same as initial pressure p_1
- But $p_1 < p_2$
 - ⇒ **reflection is expansion**
- No expansion shocks, so reflection is smooth (continuous) set of expansion waves

