


Strong and Weak Oblique Shocks

- As we have seen, it is possible to get two solutions to equation (VII.26)

$$\tan \delta = \left[\frac{2/\tan \theta (M_1^2 \sin^2 \theta - 1)}{M_1^2 (\gamma + \cos 2\theta) + 2} \right]$$

– 2 possible values of θ for given (δ, M_1)

– e.g.,



- Examine graphical solution

Graphical Solution

- Weak shocks**

– smaller θ

– $\theta_{\min} = \mu$

– usually

$M_2 > 1$


- Strong shocks**

– $\theta_{\max} = 90^\circ$
(normal shock)

– always $M_2 < 1$


- Both for $\delta = 0$

– no turn for normal shock or Mach wave



Which Solution Will Occur?

- Depends on upstream versus downstream pressure
 - e.g., back pressure
 - p_2/p_1 large for strong shock
small for weak shock
- Internal Flow
 - can have p_2 much higher or close to p_1
- External Flow
 - downstream pressure usually close to upstream p (both near p_{atm})




Strong Weak Oblique Shocks -3
Copyright © 2001 by Jerry M. Seltzman. All rights reserved.

AE3450

Maximum Turning Angle

- Given M_1 , no straight oblique shock solution for $\delta > \delta_{max}(M)$
- Given δ , no solution for $M_1 < M_{1,min}$
- Given fluid (γ), no solution for any M_1 beyond δ_{max} e.g., $\sim 45.5^\circ$ ($\gamma=1.4$)




Strong Weak Oblique Shocks -4
Copyright © 2001 by Jerry M. Seltzman. All rights reserved.

AE3450

Detached Shock

- What does flow look like when no straight oblique shock solution exists?
 - **detached shock/bow shock**, sits ahead of body/turn
 - normal shock at centerline (flow subsonic to negotiate turn); curves away to weaker shock



Strong Weak Oblique Shocks - 5
Copyright © 2001 by Jerry M. Seltman. All rights reserved.

AE3450